

Find us at:

www.gullstop.co.uk

www.pigeonstop.co.uk

www.birdstop.co.uk



Anti-Perch Spike Fitting Instructions

Point System Installation (Pigeons and Gulls)

Installing point systems is very easy – simply glue the strips into position. Or if installing on wood, you can screw them. There are a few key things to remember please see overleaf for step by step instructions.

Help line: 01903 538 488 Mon. – Sat. (8am – 6pm)
Ask us about our innovative window clips and gutter clips for AviPoint™ installations

Surface preparation

The surface to be adhered to MUST be dry and free from any contamination.

Only use *Silirub Spike Adhesive* from Seagull Deterrent Systems, or if the surface is slightly damp then use our *Fix All High Tack* adhesive.

Remove all dirt, droppings, flaking paint etc using a scraper and/or wire brush.

Remove any grease, oily deposits and lead patination with a surface cleaner

Important Tip > Prime porous surfaces such as concrete, brickwork, asphalt or roof tiles by scrubbing a small amount of the adhesive into the surface that is to be adhered to, prior to sticking down the strips. Use an old scrubbing brush that can be thrown away afterwards.



Positioning

The tips of the spikes should overhang the leading edge of any ledges, parapets or sills by about 10 mm. This is in order to stop the birds gaining an initial foothold as they approach the surface.

If parallel rows of spikes are to be laid then a 65mm gap can be allowed between adjacent rows.



Gluing

Apply a generous bead of silicone adhesive along the entire base of the strip using the built-in glue groove.



Press the strip down firmly on the surface to which it is to be applied so that rivets of glue come up through the holes in the base. Do not disturb the spike for at least 24 hours after gluing.



Cutting to size

Where less than an entire strip (33cm) is required, grooves set perpendicular to the base of the strip are provided for easy reduction in size. Simply snap-off as much as you require.